

## NERO BATHROOM GLASS INSTALLATION INSTRUCTIONS

EN [www.andres.glass](http://www.andres.glass)



**PLEASE HANDLE AND INSTALL THE GLASS WITH CARE, AS TEMPERED GLASS CAN BREAK IF ITS CORNERS AND EDGES CONTACT A HARD SURFACE!**

**Before installing or using the product, read the installation, use, maintenance and warranty instructions.**






Figure 1




Figure 2: Top view

1. Check the length of the U-channel and glass. The bottom and top U-channel should be about 20 mm shorter than the glass, and the longer vertical U-channels should be about 6 mm longer than the glass. (Fig 1)

2. Choose a suitable location for the U-channel on the edge of the bathtub. (Fig 2)

NB! Since the slopes of the bathtub rim and walls can be different, you can adjust the glass yourself accordingly if necessary.




Figure 3




Figure 4

3. Place the longer U-channel vertically on the wall using a level so that the edge of the U-channel is flush with the marked dot and the end of the channel is against the edge of the bathtub. Mark the holes in the channel (the locations of the dowel holes) on the wall and remove the channel. If marks remain on the edges of the ceramic tiles, try turning the channel the other way and making the marks again. (Fig 3)

4. Drill holes in the marked locations for the dowels included in the kit. Use a dedicated router bit or a drill without impact mode to avoid damaging the ceramic tiles.

5. Clean the holes and the wall from dust and push the dowels into the drilled holes so that the outer end of the dowel is flush with the wall.

6. Place the vertical channel on the wall and secure with screws.

7. Place the shorter U-channel on the edge of the bathtub, with the end against the U-channel on the wall and parallel to the opposite wall. (Fig 4)

8. Check the distance with a tape measure and mark the position of the channel on the edge of the bathtub.

9. Remove the channel. Clean the edge of the bathtub under the shorter U-channel with a suitable cleaning agent.




Figure 5




Figure 6

10. Remove the cover film from the double-sided tape on the U-channel and place the channel on the edge of the bathtub in the marked position. Press the channel firmly, holding the pressure for about 30 seconds. (Fig 5)

NB! If desired, the lower U-channel can also be installed on the edge of the bathtub with screws, if the bathtub structure allows it.

11. Fill the U-channel on the wall and the edge of the bathtub with an even silicone strip. (Fig 6)




Figure 7




Figure 8

12. Place the bathtub glass between the U-channels and press it both towards the wall and down so that the silicone adheres to the glass. (Fig 7)

NB! Do not push the glass against the U-channel with force, as this may cause the glass to break!

13. Make sure that the outer vertical glass edge is longer than the bottom U-channel.

NB! If the bathtub is to be at a slight angle, you can add supporting wedges between the glass and the U-channel if necessary.

14. Remove any excess silicone that has squeezed out between the glass and the channels.

15. Check the suitability of the U-channels that have not yet been installed. If necessary, adjust the glass before the silicone dries. Use a level to ensure that the edge of the glass remains vertical.

16. If the bathtub is to be at a slight angle, you can add supporting wedges between the glass and the U-channel if necessary.

17. Fill the U-channels that have not yet been installed with an even strip of silicone and install the shorter U-channel on the top of the glass first and the longer vertical U-channel last. (Fig 8)

18. Make sure the channels are aligned and there are no gaps between them. Remove any excess silicone that has squeezed out between the glass and the channel.




Figure 9: Top view




Figure 10: Top view

19. Install the telescopic tube at a 45 degree angle to the wall. Since the telescopic tube is adjustable, choose the mounting location according to your preference, but we recommend installing it towards the outer corner of the glass. (Fig 10)
20. Install the gaskets included with the tube between the telescopic tube mounting bracket (3) (the part that attaches to the glass and the U-channel) to prevent the glass from coming into contact with the metal.
21. Carefully place the telescopic tube on the U-channel on the glass, in the previously measured and planned location. Make sure the telescopic tube is level.
22. Mark on the wall where the mounting hole (a) needs to be drilled and remove the telescopic tube. (Fig 9)
23. Drill a hole for the dowel (a) at the marked location, clean the hole of any dust and insert the dowel.
24. Unscrew the screw (1) on the telescopic tube and remove the wall-mounting part (b). (Fig 10)
25. Install the part (b) into the hole (a) previously drilled in the wall and secure with a screw. (Fig 9)
26. Take the telescopic tube and carefully install it into the wall mount (b) and rest the other end (3) on the planned location, on the glass and the U-channel. (Fig 10)
27. Tighten and secure the screw (1). NB! The mounting point must face upwards!
28. Fix the telescope mount (3) to the glass and U-channel with a screw. NB! It is important that you have previously installed the gaskets included in the kit between part (3)! Metal parts must not come into contact with the glass, which could cause the glass to break.
29. Adjust the glass using a spirit level and fix the telescopic tube using the screws (2) with the positions facing upwards.
30. If the installed channels have protective films on them, remove them.




Figure 11




Figure 12

31. Apply an even silicone strip to the edges of the U-channel on the inside (Figure 11) and outside (Figure 12) of the bathtub glass.

32. Remove excess silicone.

33. For the next 24 hours, avoid getting water on the silicone until it is completely dry.