

SARA SHOWER WALL INSTALLATION INSTRUCTIONS

EN www.andres.glass



PLEASE HANDLE AND INSTALL THE GLASS WITH CARE, AS THE TEMPERED GLASS CAN BREAK IF ITS CORNERS AND EDGES COME INTO CONTACT WITH A HARD SURFACE!

Before installing or using the product, read the installation, usage, maintenance and warranty instructions.






Figure 1




Figure 2

1. Place the U-profile on the floor, with the end against the wall and parallel to the opposite wall. Choose the distance of the U-profile from the opposite wall according to your wishes, based on the working width of the telescopic tube. (Figure 1)

2. Measure the required distance from the corner of the wall and make a mark. Remove the U-profile.

3. Check the length of the U-profile and the glass, the U-profile should be approximately 8 mm longer than the glass. (Figure 2)

EN 




Figure 3




Figure 4

4. Clean the floor surface under the U-profile with a suitable cleaning agent.

5. Remove the backing film from the double-sided tape on the profile and place the profile on the floor in the marked location. Press the lath firmly, holding the pressure for about 30 seconds. (Figure 3)

6. Before installing the glass, check the slope of the floor and add wedges if necessary.

7. Make the appropriate measurements on the vertical side of the glass, where the mounting locations for the mounting clamps are marked. (Figure 4)

8. Make marks on the wall using a level or laser and drill the holes for the dowels for the clamps.




Figure 5




Figure 6

9. Take the clamps included in the kit and attach them to the wall using the screws provided. (Figure 5)

10. Fill the U-profile with an even silicone strip.

11. Before installing the shower glass, make sure to leave an 8 mm gap between the wall and the glass and ensure that the glass and clamp attachment points overlap. (Figure 6)

12. Place the shower glass between the U-profile and press it downwards so that the silicone adheres to the glass.

NB! Do not forcefully push the glass against the U-profile, as this may cause the glass to break!

13. Make sure that the outer vertical edge of the glass is aligned with the edge of the bottom U-profile.

NB! If the floor has a slight slope, you may add supporting wedges between the glass and the U-profile as needed.

14. Remove any excess silicone that has been squeezed out between the glass and the U-profile.

15. Secure the clamps with the screws provided in the kit.




Figure 7




Figure 8

16. Take the gasket included in the kit and cut the parts to the correct lengths, on the hinge and wall sides. Cut out three different parts and install the gaskets. (Figure 7)

17. Fix the glass and mounting clamps using a spirit level, adjust the clamps if necessary.

18. Install the telescopic tube at a 90-degree angle to the wall. The glass clamp must be positioned no more than 20 cm from the corner of the glass. (Figure 8)

19. Install the gaskets included with the tube between the telescopic tube mounting clamp (3) (the part that attaches to the glass) to prevent the glass from coming into contact with the metal. (Figure 10)

20. Carefully place the telescopic tube on the glass, in the previously measured and planned location. Make sure that the telescopic tube is vertically level. (Figure 8)

21. Mark the spot on the wall for drilling the mounting hole (a) (see Figure 9), and remove the telescopic tube.

EN 




Figure 9




Figure 10

22. Drill the hole for the dowel (a) at the marked location, remove any dust from the hole, and insert the dowel. (Figure 9)
23. Unscrew the screw (1) on the telescopic tube (see Figure 10) and remove the wall-mounted part (b) (see Figure 9).
24. Insert part (b) into the previously drilled hole (a) in the wall and secure it with a screw. (Figure 9)
25. Take the telescopic tube and carefully install the wall mount (b) inside the telescopic tube and rest the other end (3) on the planned location, on the glass. (Figure 10)
26. Tighten and secure screw (1). NB! The mounting point must be oriented upwards!
27. Secure the telescopic mount to the glass with screw (3). NB! It is important that you have previously installed the gaskets included in the set between part (3) Metal parts must not come into contact with the glass, as this may cause the glass to break.
28. Adjust the glass using a level and secure the telescopic tube with screws (2), with their heads facing upwards.
29. If the installed profiles have protective films, remove them.




Figure 11




Figure 12

30. Apply an even bead of silicone to the edges of the U-profiles on both the inside (Figure 11) and outside (Figure 12) of the shower enclosure.

31. Remove excess silicone.

32. Avoid getting water on the silicone for the next 24 hours until it is fully cured.