

## UNO SHOWER WALL INSTALLATION INSTRUCTIONS

---

EN [www.andres.glass](http://www.andres.glass)



**PLEASE HANDLE AND INSTALL THE GLASS WITH CARE, AS THE TEMPERED GLASS CAN BREAK IF ITS CORNERS AND EDGES COME INTO CONTACT WITH A HARD SURFACE!**

**Before installing or using the product, read the installation, usage, maintenance and warranty instructions.**






Figure 1

1. Select the distance of the U-profile from the wall according to your wishes, based on the working width of the telescopic tube. Measure the required distance from the wall and make a mark. (Figure 1)

2. Remove the profile.

3. Check the length of the U-profile and the glass, which must be the same size.




Figure 2

4. Clean the floor surface under the U-profile with a suitable cleaning agent.

5. Remove the backing film from the double-sided tape on the profile and place the profile on the floor in the marked location. Press the lath firmly, holding the pressure for about 30 seconds. (Figure 2)




Figure 3

6. Fill the U-profile with an even silicone strip. (Figure 3)

7. Place the shower glass between the U-profile (straight from top to bottom) and press downwards to allow the silicone to adhere to the glass.

NB! Do not push the glass against the U-profile on the floor with force, as this may cause the glass to break!

8. Make sure that the edges of the outer vertical panes and the edge of the lower U-profile are in line.

NB! If the floor has a slight slope, you may add supporting wedges between the glass and the U-profile as needed.

9. Remove any excess silicone that has been squeezed out between the glass and the U-profile.




Figure 4




Figure 5

10. One of the installers shall hold the glass while the other installs the telescopic tubes.

11. Install the telescopic tubes at right angles to the wall. Use a level to ensure the glass is in the correct position. (Figure 4)

12. The glass clamps must be located a maximum of 20 cm from the corner of the glass. (Figure 5)

13. Install the gaskets supplied with the tubes between the telescopic tube mounting clamps (3) (Figure 7) (the parts that attach to the glass) to prevent the glass from coming into contact with the metal.

14. Carefully place the telescopic tubes on the glass, in the previously measured and planned location. Make sure the telescopic tubes are level.

15. Mark the wall where the mounting holes (a) need to be drilled (Figure 6) and remove the telescopic tubes.




Figure 6




Figure 7

16. Drill the dowel holes (a) at the marked location, clean the holes of any dust and insert the dowels. (Figure 6)
17. Unscrew the screw (1) on the telescopic tubes (Figure 7) and remove the wall-mounting piece (b) (Figure 6).
18. Install the parts (b) into the holes (a) previously drilled in the wall and secure with screws. (Figure 6)
19. Take the telescopic tubes and carefully install the wall mount (b) inside the telescopic tube and rest the other end (3) on the planned location, on the glass. (Figure 7)
20. Tighten and secure screw (1). NB! The mounting point must be oriented upwards!
21. Secure the telescopic mount to the glass with screw (3). NB! It is important that you have previously installed the gaskets included in the set between part (3) Metal parts must not come into contact with the glass, as this may cause the glass to break.
22. Adjust the glass using a level and secure the telescopic tube with screws (2), with their heads facing upwards.
23. If the installed profile has protective films on it, remove them.




Figure 8




Figure 9

24. Apply an even bead of silicone to the edges of the U-profiles on both the inside (Figure 8) and outside (Figure 9) of the shower enclosure.

25. Remove excess silicone.

26. Avoid getting water on the silicone for the next 24 hours until it is fully cured.