

## FASCINO SHOWER ENCLOSURE INSTALLATION INSTRUCTIONS

EN [www.andres.glass](http://www.andres.glass)



**PLEASE HANDLE AND INSTALL THE GLASS WITH CARE, AS THE TEMPERED GLASS CAN BREAK IF ITS CORNERS AND EDGES COME INTO CONTACT WITH A HARD SURFACE!**

**Before installing or using the product, read the installation, usage, maintenance and warranty instructions.**






Figure 1

1. Start the installation with the single-hinge glass door.
2. Measure the distance of the hinge bar profile from the parallel wall according to the planned shower enclosure and make a mark. (Figure 1)
3. Using a spirit level, place the hinge bar profile vertically on the wall so that the edge is flush with the edge of the floor.
4. Mark the holes in the profile (the locations of the dowel holes) on the wall and remove the profile from the wall. If marks remain on the edges of the ceramic tiles, try turning the profile the other way and making the marks again.
5. Drill holes in the marked locations for the dowels included in the kit. Use the designated milling cutter or a drill without hammer mode to avoid damaging the ceramic tiles.
6. Clean the holes and the wall from dust and push the dowels into the drilled holes so that the outer end of the dowel is flush with the wall.

EN 




Figure 2




Figure 3

7. To attach the profile, apply silicone to the edges of the profile and place it on the wall, according to the previously marked locations. (Figure 2)

8. Secure the profile with screws. Remove any excess silicone that has been squeezed out between the glass and the U-profile.

9. Place wooden blocks on the floor (maximum thickness 10 mm) to support the door glass from the package, which already has the manufacturer-installed single hinge attached. (Figure 3)

NB! Make sure that the glass does not come into contact with the floor tiles, as it is tempered glass and may shatter upon impact!




Figure 4

10. Carefully rest the bottom edge of the glass on the support blocks. Slide the mono-hinged glass into the wall-mounted hinge profile, with the movement directed toward the wall. (Figure 4)




Figure 5

11. Make sure that the glass is properly secured inside the hinge profile and that the edge of the glass is plumb. (Figure 5)




Figure 6

12. Mark the screw mounting positions on the profile from both inside and outside the shower. Measure and mark one side of the profile about 10 cm from the top and bottom, and the other side at about 20 cm. To ensure the shower glass stays firmly in place, it is important that the screws are not aligned with each other. (Figure 6)

EN 




Figure 7

13. Begin by drilling the top hole, going through both the hinge profile and the hinge. Drill the holes carefully so that the drill only passes through one half of the profiles, not the entire product. (Figure 7)

14. Attach the hinge to the hinge profile by screwing the stainless steel screws (4 pcs) included in the kit into the drilled holes and add the decorative covers.

NB! Do not overtighten the screws! Overtightening may cause the screws to break and damage the profile.





Figure 8



15. Next, install the stationary glass wall with the telescopic tube.

16. Select the distance of the U-profile from the wall according to the glass door already installed. (Figure 8)

17. Measure the required distance from the corner of the wall and make marks. The distance must be measured both on the floor and on the wall.

EN   




Figure 9




Figure 10

18. Check the length of the U-profile and glass. The bottom U-profile should be about 10 mm shorter than the glass and the longer vertical U-profile should be about 3 mm longer than the glass. (Figure 9)

NB! As the floors and walls may have varying slopes, you can adjust the glass accordingly if necessary.

19. Place the longer U-profile vertically on the wall using a level so that the edge of the U-profile is flush with the marked dot and the end of the slat is against the floor. Mark the holes in the profiles (the locations of the dowel holes) on the wall and remove the profile. If marks remain on the edges of the ceramic tiles, try turning the profile the other way and making the marks again. (Figure 10)

20. Drill holes in the marked locations for the dowels included in the kit. Use the designated milling cutter or a drill without hammer mode to avoid damaging the ceramic tiles.

21. Clean the holes and the wall from dust and push the dowels into the drilled holes so that the outer end of the dowel is flush with the wall.

22. Place the vertical profile on the wall and secure with screws.

EN   




Figure 11

23. Place the shorter U-profile on the floor, with the end against the U-profile on the wall and parallel to the opposite wall. (Figure 11)

24. Check the distance with a tape measure and mark the position of the profile on the floor.

25. Remove the profile.

26. Clean the floor surface under the shorter U-profile with a suitable cleaning agent.




Figure 12

27. Remove the backing film from the double-sided tape on the profile and place the profile on the floor in the marked location. Press the lath firmly, holding the pressure for about 30 seconds. (Figure 12)




Figure 13

28. Fill the U-profiles on the wall and floor with an even silicone strip. (Figure 13)




Figure 14

29. Place the shower glass between the U-profiles and press it both towards the wall and downwards so that the silicone adheres to the glass. (Figure 14)

NB! Do not forcefully push the glass against the U-profile, as this may cause the glass to break!

30. Make sure that the outer vertical edge of the glass is aligned with the edge of the bottom U-profile.

NB! If the floor has a slight slope, you may add supporting wedges between the glass and the U-profile as needed.

31. Remove any excess silicone that has been squeezed out between the glass and the U-profile.




Figure 15

32. Install the telescopic tube at a 90-degree angle to the wall. The glass clamp must be positioned no more than 20 cm from the corner of the glass. (Figure 15)

33. Install the gaskets included with the tube between the telescopic tube mounting clamp (3) (the part that attaches to the glass) to prevent the glass from coming into contact with the metal. (Figure 17)

34. Carefully place the telescopic tube on the glass, in the previously measured and planned location. Make sure that the telescopic tube is vertically level. (Figure 15)

35. Make a mark on the wall (Figure 15) for drilling the mounting hole (a) (Figure 16) and remove the telescopic tube.




Figure 16




Figure 17

36. Drill the hole for the dowel (a) at the marked location, remove any dust from the hole, and insert the dowel. (Figure 16)

37. Unscrew the screw (1) on the telescopic tube (see Figure 17) and remove the wall-mounted part (b) (see Figure 16).

38. Insert part (b) into the previously drilled hole (a) in the wall and secure it with a screw. (Figure 16)

39. Take the telescopic tube and carefully install the wall mount (b) inside the telescopic tube and rest the other end (3) on the planned location, on the glass. (Figure 17)

40. Tighten and secure screw (1). NB! The mounting point must be oriented upwards!

41. Secure the telescopic mount to the glass with screw (3). NB! It is important that you have previously installed the gaskets included in the set between part (3) Metal parts must not come into contact with the glass, as this may cause the glass to break.

42. Adjust the glass using a level and secure the telescopic tube with screws (2), with their heads facing upwards.




Figure 18




Figure 19

43. Next, adjust the single hinge of the glass door that was installed first.

44. To adjust the mono hinges, loosen both mounting screws (1) on the washer by a few turns using the included Allen key. (Figure 18)

45. Move the glass (2) to the desired position where you want to secure the door.

46. Once the glass (2) is in the desired position, tighten the washer mounting screws (1).

NB! Do not overtighten the screws! Overtightening may cause the screws to break and damage the profile.

47. Remove the blocks from under the glass. (Figure 19)

48. Install the brush seals included in the kit on the bottom edge of the door glass, and place the magnetic seals vertically at the intersection of the glass wall and the glass door.

NB! If necessary, cut the seals to the appropriate size.

49. Install the handle included in the package.

50. If the installed profiles have protective films on them, remove them.




Figure 20




Figure 21

51. Apply an even bead of silicone to the edges of the U-profiles on both the inside (Figure 21) and outside (Figure 20) of the shower enclosure.

52. Remove excess silicone.

53. Avoid getting water on the silicone for the next 24 hours until it is fully cured.